



For Professional GAMERS

SCAN ME!



FOR MORE INFO

Powered by TSCO  
[www.tSCO.ir](http://www.tSCO.ir)



## MAXIMIZE YOUR DEVICE WITH GM-2035W SOFTWARE

Access advanced options and granular control as you rebind buttons, assign macros, personalize device lighting and more with the unified hardware configuration tool.

<https://tSCO.ir/Device-Driver/2035.rar>

Internet connection is required for installation and updates.



## GET HELP WITH TSCO GAME SUPPORT

We're here to assist you with your TSCO game device. Find software downloads, register your product, or contact us by phone, chat or email if you have any questions.

<https://service.tSCO.ir/>




# GM 2035W GAMING MOUSE



## PACKAGE CONTENT

- GM-2035W
- Wireless USB Dongle
- Charging Cable
- User Manual
- Guarantee Card



## WHAT'S INSIDE



## محتویات بسته بندی

- GM-2035W
- دانگل USB
- کابل شارژ
- دفترچه راهنما
- کارت گارانتی

## اجزاء محصول



- A Mouse button 1
- B Mouse button 2
- C Mouse button 3
- D Mouse button 4
- E Mouse button 5
- F Mouse button 6
- G Mouse button 7

- H 16,000 DPI Optical Sensor (PixArt PAW 3335)
- I Switch (ON/OFF/ Eco mode)
- J Wireless USB dongle compartment
- K Ultraslick Mouse feet
- L Wireless USB dongle
- M Charging cable

Max DPI: 16000

Max Polling Rate: 1000Hz

The DPI and Polling Rate and Button's Function can be customized using **GM-2035W Software**.

## WHAT'S NEEDED

### PRODUCT REQUIREMENTS :

- PC with a free USB port

### GM-2035W SOFTWARE REQUIREMENTS:

- Windows® 7 64-bit (or higher)
- Internet connection for software installation

## LET'S GET YOU COVERED

You've got a great device in your hands complete with a 18 month limited warranty coverage.

To activate your warranty service; please send serial number which is written on guarantee card or product to **20004243**.



- H سنسور ۱۶۰۰۰ DPI (PixArt PAW 3335)
- I کلید روشن/خاموش/حالت اکو
- J جایگاه دانگل USB
- K پایه زیر ماوس
- L دانگل USB
- M کابل شارژ

- A کلید شماره ۱
- B کلید شماره ۲
- C کلید شماره ۳
- D کلید شماره ۴
- E کلید شماره ۵
- F کلید شماره ۶
- G کلید شماره ۷

حداکثر DPI: ۱۶۰۰۰

حداکثر Polling Rate: ۱۰۰۰Hz

مقدار DPI، Polling Rate و عملکرد کلیدها می‌تواند با نرم افزار **GM-2035W** تنظیم شود.

## سیستم مورد نیاز

### سیستم مورد نیاز نرم افزار GM-2035W:

- ویندوز ۷ (۶۴ بیت) و بالاتر
- اتصال اینترنت برای نصب نرم افزار

### سیستم مورد نیاز محصول:

- کامپیوتر با پورت USB

## فعالسازی گارانتی


این محصول دارای گارانتی ۱۸ ماهه می‌باشد. جهت فعالسازی گارانتی، شماره سریال درج شده بر روی کارت گارانتی یا محصول را به شماره **۲۰۰۰۴۲۴۳** ارسال نمایید.



## GETTING STARTED

### CHARGING YOUR GM-2035W

Plug the charging cable from your computer's USB port to your **GM-2035W**.




For best results, please fully charge your GM-2035W before using it for the first time. A depleted battery will be fully charged in approximately 4 hours. If the GM-2035W has not been used for an extended period, you may need to recharge it before use.

The GM-2035W Requires a USB connection that is able to supply sufficient power to charge the battery. The battery charging process of the GM-2035W may be affected if connected to a non-powered USB hub or non-powered USB ports found on certain keyboard and other peripherals. When in doubt, it is preferable to connect the GM-2035W directly to the USB port of your computer.

### LOW POWER INDICATOR

The GM-2035W will flash red twice in repeated intervals to indicate that the battery's power is less than 20%. This lighting sequence will repeat until the battery is drained or the mouse is connected to the PC via the charging cable.


**Up to 75 hours** (in eco mode)



## نحوه کار با محصول

### شارژ کردن GM-2035W

کابل شارژ را از پورت USB کامپیوتر خود به ماوس وصل کنید.




برای استفاده بهتر، لطفاً قبل از اولین استفاده، GM-2035W را شارژ کنید. مدت زمان لازم برای شارژ باتری خالی، تقریباً ۴ ساعت است. در صورت عدم استفاده طولانی مدت از دستگاه، قبل از استفاده آن را شارژ کنید.

ماوس GM-2035W برای شارژ نیاز به پورت USB دارد که قادر باشد توان کافی برای شارژ باتری را تأمین کند. فرآیند شارژ باتری GM-2035W ممکن است در صورت اتصال به یک هاب USB بدون منبع تغذیه مستقل یا پورت های USB موجود در کیبورد و سایر لوازم جانبی تحت تأثیر قرار گیرد. برای اطمینان بهتر است GM-2035W را مستقیماً به پورت USB کامپیوتر متصل کنید.

### نشان گر هشدار شارژ باتری


زمانی که شارژ باتری کمتر از ۲۰ درصد باشد GM-2035W در فواصل زمانی ثابت، دوبار با نور قرمز، شروع به چشمک زدن می کند. چشمک زدن تا زمانی که باتری شارژ شده یا ماوس به کامپیوتر وصل شود ادامه دارد.



**تا ۷۵ ساعت** (در حالت ECO)

## USE THE WIRELESS USB DONGLE

- 1- Remove the wireless USB dongle from **GM-2035W**.
- 2- Insert the wireless dongle into your computer's USB port.
- 3- Switch on the **GM-2035W**. Your device is now ready for use in wireless mode.
- 4- You can switch between Eco/On/Off modes by pressing mouse bottom key.




⚠ This connection also acts as the wired mode for your GM-2035W. (Without dongle)

## PERSONALIZE YOUR MOUSE

Change your mouse's DPI, Buttons function, RGB mode and Polling Rate to match your playstyle with using the **GM-2035W** Software.


**Note:** To install the **GM-2035W** Software gaming mouse, visit;  
<https://tsco.ir/Device-Driver/2035W.rar>

DPI	Designated Color
1200	Blue 
1600	Green 
2400	Red 
3200	Purple 
4800	Yellow 
6000	Light Blue 
8000	Orange 
16000	White 



## نحوه کار با دانگل USB

- 1- دانگل USB را از قسمت تعبیه شده در **GM-2035W** جدا کنید.
- 2- دانگل USB را به پورت USB وصل کنید.
- 3- **GM-2035W** را روشن کنید. ماوس برای استفاده در حالت بی سیم، آماده است.
- 4- با استفاده از دکمه‌ی زیر ماوس می‌توانید بین حالت اکو مود و روشن انتخاب کنید.











⚠ GM-2035W در دو حالت بی سیم و سیمی قابل استفاده است. (بدون دانگل)


## شخصی سازی قابلیت های ماوس

با استفاده از نرم افزار **GM-2035W** می‌توانید تنظیمات مربوط به DPI، عملکرد هر کدام از کلیدها، حالت RGB و Polling Rate را به دلخواه تنظیم کنید.

**نکته:** برای نصب نرم افزار **GM-2035W**، به نشانی زیر مراجعه کنید؛

<https://tsco.ir/Device-Driver/2035W.rar>

رنگ طراحی شده	DPI
 آبی	1200
 سبز	1600
 قرمز	2400
 بنفش	3200
 زرد	4800
 آبی کم رنگ	6000
 نارنجی	8000
 سفید	16000



## SAFETY AND MAINTENANCE

### SAFETY GUIDELINES

In order to achieve maximum safety while using your **GM-2035W** see below for more comfort.

1. Avoid looking directly at the tracking beam of your mouse or pointing the beam in anyone else's eye.
2. Should you have trouble operating the device properly and troubleshooting does not work unplug the device and contact the (021)42435000 hotline or go to service.tscsco.ir for assistance.
3. Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.
4. Keep the device away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F).

Should the temperature exceed this range, unplug and switch off the device in order to let the temperature stabilize to an optimal level.

## COMFORT

Research has shown that long periods of repetitive motion, improper positioning of your computer peripherals, incorrect body position and poor habits may associated with physical discomfort and injury to nerves, tendons and muscles.

Below are some guidelines to avoid injury and ensure optimum comfort while using your **GM-2035W**;

1. Position your keyboard and monitor directly in front of you with your mouse next to it. Place your elbows next to your side not too far away and your mouse within easy reach.

## نکات ایمنی و نگهداری از محصول

دستورالعمل‌های ایمنی

برای استفاده هرچه بهتر از محصول **GM-2035W**، لازم است دستورالعمل‌های زیر را انجام دهید:

۱. از نگاه کردن مستقیم به نور اشعه ماوس یا گرفتن اشعه در برابر چشم افراد دیگر خودداری کنید.
۲. در صورتی که دستگاه به درستی کار نکند لطفاً ماوس را جدا کرده و با شماره 42435000(021) تماس بگیرید و یا به سایت service.tscsco.ir برای راهنمایی مراجعه نمایید.
۳. لطفاً دستگاه را باز نکنید و قطعات دستگاه را از هم جدا نکنید زیرا علاوه بر آسیب رسیدن به محصول باعث باطل شدن گارانتی آن نیز می‌شود.
۴. دستگاه را در مجاورت مایعات و رطوبت قرار ندهید. از دستگاه در محدوده دمای 0°C (32°F) تا 40°C (104°F) استفاده کنید. اگر دما از حد مجاز بالاتر رفت، دستگاه را خاموش کرده و اجازه دهید دستگاه به دمای مناسب تعیین شده بازگردد.

## استفاده صحیح و راحت

تحقیقات نشان داده اند که انجام حرکات تکراری، قرارگیری کامپیوتر و لوازم جانبی آن در موقعیت نامناسب بدن هنگام کار و عادات نامناسب در نشستن، با بیماری‌ها و دردهای مرتبط با اعصاب، تاندون‌ها و ماهیچه‌ها ارتباط مستقیم دارد. در ادامه، نکات لازم برای قرارگیری در موقعیت فیزیکی مناسب و جلوگیری از آسیب به بدن هنگام کار با ماوس **GM-2035W** آورده شده است؛

۱. کیبورد و مانیتور را مستقیماً در برابر خود قرار دهید و ماوس در کنار کیبورد قرار گیرد. آرنج‌تان را در فاصله نزدیک به نحوی که دسترسی به ماوس آسان باشد قرار دهید.
۲. ارتفاع صندلی و میز کار خود را طوری تنظیم کنید که کیبورد و ماوس کاملاً برابر / پایین‌تر از آرنج‌تان قرار گیرد.
۳. پاهای خود را در موقعیت مناسب و حالت صاف و شانه‌های را در حالت آزاد و استراحت قرار داده و حفظ کنید.

- Adjust the height of your chair and table so that the keyboard and mouse are at or below elbow height.
- Keep your feet well supported, posture straight and your shoulders relaxed.
- During gameplay, relax your wrist and keep it straight. if you do the same tasks with your hands repeatedly, try not to bend, extend or twist your hands for long periods.
- Do not rest your wrists on hard surfaces for long periods. Use a wrist rest to support your wrist while gaming.
- Customize the button on your mouse to suit your gaming style in order to minimize repetitive or awkward motions while gaming.
- make sure that your mouse fits comfortably in your hands.
- Do not sit in the same position all day. Get up step away from your desk and do exercises to stretch your arms, shoulders, neck and legs.
- If you should experience and physical discomfort by using your mouse such as pain, numbness, or tingling in your hands, wrists, elbows, shoulders, neck or back, please consult a qualified medical doctor immediately.

## MAINTENANCE AND USE

The **GM-2035W** requires minimal maintenance to keep it in optimum condition. Once month we recommend you clean it using the soft cloth or cotton swap to prevent dirt buildup. Do not use soap or other cleaning agents.

To get ultimate experience in movement and control, we highly recommend the premium TSCO mousepad.

Some surface will cause undue wear on the feet requiring constant care and eventual replacement. Do note that the sensor of **GM-2035W** is "tuned" or optimized especially for the TSCO mousepad. This means that the sensor had been tested extensively to comfort that the **GM-2035W** Reads and tracks best on the TSCO mousepad.

- در طول بازی و کار با دستگاه، مچ دست خود را آزاد و در حالت صاف نگه دارید. اگر در تمام مدت کار با ماوس، به طور مستمر فعالیت تکراری انجام می‌دهید مچ دستتان را برای مدت طولانی، خم نکنید.
- مچ دستتان را برای مدت طولانی روی سطوح سخت قرار ندهید. هنگام بازی از یک استراحتگاه مچ دست استفاده کنید.
- کلیدهای ماوس را با توجه نوع بازی و به منظور به حداقل رساندن حرکات تکراری و سخت، تنظیم و شخصی سازی کنید.
- ماوس را کاملاً با دست خود تنظیم کرده و از قرارگیری مناسب آن اطمینان حاصل کنید.
- از نشستن یک جا در مدت طولانی خودداری کنید. از پشت میز کامپیوتر بلند شده و تمرینات کششی بازوها، شانه‌ها، گردن و ساق را انجام دهید.
- اگر در صورت وجود رعایت موارد گفته شده، هنگام استفاده از ماوس احساس درد در مچ، کرختی انگشتان، سوزش در ناحیه دست‌ها، مچ‌ها، آرنج‌ها، شانه‌ها، گردن یا کمر داشتید به پزشک متخصص مراجعه کنید .

## نکات مرتبط با نگهداری و تعمیرات دستگاه

برای نگهداری و مراقبت از **GM-2035W** رعایت نکات حداقلی و عادی، کافی خواهد بود.

هرماه یکبار ماوس را با پارچه کتان یا اسفنج نرم پاک کنید.

از صابون و مواد شیمیایی استفاده نکنید.

پیشنهاد ما به شما برای جابجایی و کنترل مناسب ماوس استفاده از ماوس پد تسکو است.

بعضی سطوح موجب ایجاد ساییدگی نامناسب بر ماوس می‌شوند که منجر به مراقبت‌های پیوسته و نهایتاً تعویض آن می‌گردد.

سنسور به کار رفته در **GM-2035W** به طور خاص برای ماوس پدهای تسکو طراحی و تنظیم شده است. این سنسور به طور وسیع و مکرر برای تسهیل و جابجایی **GM-2035W** روی ماوس پد تسکو تست شده است.